

Sealmax Universal Push-In Replacement Weatherstripping Door Kit is for most exterior doors.

Time Required: 10 minutes

Tools Required: Measuring tape, scissors

Step 1 **Measure**
Measure the header (top) and left + right jambs (sides) of the door you are sealing.

Step 2 **Cut**
Use your measurements and cut the short piece for the header and the long pieces for the left + right jambs.

Step 3 **Push In**
Insert the short piece into the header with the open sides of the V shape facing upwards. Press firmly all the way across to ensure the piece is well inserted.

Step 4 **Repeat**
Repeat step 3 with each of the long pieces for the left + right jambs.

Tips

! Remove old weatherstripping

Your door's old worn weatherstripping will slide out. Use the same channel to install your new Universal Door Kit.

! Use the right pieces.

There are 3 pieces in your Universal Door Kit. Use the shorter piece for the header of your door and the longer pieces for the left + right jambs.

! Clean the surface.

Weatherstripping installs best on clean, dry surfaces. Remove any dirt, debris with a clean cloth and light cleaner.

To watch our How-to video for installing this product visit www.sealmax.com and click on Videos.