

Sealmax High Performance Adhesive Backed Woven Pile replacement weatherstripping can be used in both windows and doors.

Time Required: 10 minutes per door/window

Tools Required: Measuring tape, scissors

Step 1 **Measure**
Measure the top, sides and bottom of the door or window you are sealing.

Step 2 **Cut**
Use your measurements and lengths of tape with your scissors.

Step 3 **Apply**
Slowly peel one end of the backing paper and push the sticky end of your cut strip into place. Continue to peel the backing paper off as you push the woven pile weatherstrip into place.

Step 4 **Repeat**
Repeat step 3 for each piece of weatherstripping for the remaining top, bottom or sides of your door or window.

Tips

! Remove old weatherstripping

If your door has old worn weatherstripping, you should try and remove it.

! Clean the surface.

Adhesive backed product works best on clean, dry surfaces. Remove any dirt, debris or old adhesive with a clean cloth and light cleaner.

To watch our How-to video for installing this product visit
www.sealmax.com and click on Videos.